


# Liberty



# Liberty

Item	Part No.	Description
1	258-35080	12V Motor
2	258-30050	Motor Locating Screw
3	258-31510	Motor Gear
4	258-30070	Grub Screw M3 x 5mm
5	258-35210	Body Casing RH
6	258-35220	Body Casing LH
7	258-33670	Casing Screw
8	258-33740	Wrist Cord
9	258-33730	Wrist Cord End
10	258-30130	Switch
11	258-30150	Switch Lead
12	258-30261	Cable Assembly <i>(includes item 12A)</i>
12A	258-30170	Cable Connector
13	258-33361	Assembly of Parts 14-20
14	258-33351	Clipper Head
15	258-30820	Gearshaft
16	258-00061	Crank Head
17	258-00057	Crank Roller
18	258-00062	Crank Roller Spring
19	258-30850	Comb Peg
20	258-30850P	Comb Peg Pin
21	258-30780	Screw M4 x 20mm
22	258-11740	Washer M4
23	252-00009	Tension Bolt

Item	Part No.	Description
24	258-10061	Tension Spring
25	258-33710	Tension Nut